

PRODUCT DATA SHEET

Sika Boom[®] Foam Cleaner

Dual purpose cleaner to remove uncured polyurethane foam from overspill and applicator guns

PRODUCT DESCRIPTION

Sika Boom[®] Foam Cleaner is an aerosol cleaner designed to remove uncured/ wet foam from tools, substrates and applicator guns. The included spray nozzle allows for external cleaning of gun nozzles, handheld can nozzles and overspill on substrates and tools, and the threaded collar allows thorough purging of applicator guns. The unique threaded collar fits most foam gun applicators, including the Sika Boom[®] range, allowing expensive applicator guns to be used repeatedly.

USES

- Cleaning uncured PU foams from applicator guns and nozzles.
- Cleaning spilt uncured PU foams from substrates and surrounding areas.

PRODUCT INFORMATION

Packaging	500 ml aerosol
Shelf Life	Use within 12 months
Storage Conditions	Store in cool dry conditions between +5 °C and +25 °C

VALUE BASE

All technical data stated in this Product Data Sheet are based on laboratory tests. Actual measured data may vary due to circumstances beyond our control.

LIMITATIONS

- Will only clean uncured foam.
- Cured foam must be removed mechanically.

CHARACTERISTICS / ADVANTAGES

- Contains a separate nozzle for hand held use to be able to clean external gun tips, canister valves and nozzles.
- Enables expensive guns to be reused again and again.
- Removes uncured spills of foam from substrates, floors and walls.

ECOLOGY, HEALTH AND SAFETY

User must read the most recent corresponding Safety Data Sheets (SDS) before using any products. The SDS provides information and advice for the safe handling, storage and disposal of chemical products and contains physical, ecological, toxicological and other safety-related data.

APPLICATION INSTRUCTIONS

SUBSTRATE PREPARATION

When cleaning spilt/excess foam, ensure surrounding areas are protected with impervious masking tape to prevent chemical attack by the solvents in this product.

APPLICATION METHOD / TOOLS

The following are recommendations for cleaning uncured foam in all common situations.

If foam in a gun is allowed to cure, the gun will become completely useless, as no solvent will dissolve PU foam once cured. The following guidelines are given to avoid unnecessary replacement of applicator guns.

- Gun foam canisters may be left attached to an applicator gun for a maximum of seven days after use. If left for longer, there is a risk of the foam curing from the nozzle inwards or propellant leaking out. If the foam canister is left attached to the gun, spray Sika Boom® Foam Cleaner over the outside of the discharge nozzle before storage to remove any residues which may seize up the valve.
- When you have finished using foam on a project, and do not intend to use the gun again within seven days, remove the foam can (CARE - GLOVES/GOGGLES). When you have read the usage/safety instructions on the canister, attach Sika Boom® Foam Cleaner to the gun by screwing the canister on to the gun adaptor until it will go no further. Take care not to over-tighten. Pull the trigger on the gun to discharge the solvent through the gun in to a suitable container. Only stop discharging the cleaner when the jet is completely clear of foam. Leave the Sika Boom® Foam Cleaner canister attached to the gun for five minutes to allow the solvent in the gun to work on any residues left inside. Pull the trigger once again until the jet is clear of all foam. Repeat this process two or three times until the gun is completely clear.

The following directions will also help prolong the life of an applicator gun.

- Always clean the threaded adaptor ring with Sika Boom® Foam Cleaner when replacing foam canisters.
- Never dismantle an applicator gun.
- Never try to clean an applicator gun with water. This will cure the foam instantly.
- When using hand-held nozzle canisters, attach the Sika Boom® Foam Cleaner nozzle to the Sika Boom® Foam Cleaner canister and squirt cleaner down the plastic nozzle until clean.

Use Sika Boom® Foam Cleaner to clean up spilled foam immediately. Attach the nozzle to the canister and spray to remove uncured foam. Check compatibility with surfaces prior to use.

LOCAL RESTRICTIONS

Please note that as a result of specific local regulations the performance of this product may vary from country to country. Please consult the local Product Data Sheet for the exact description of the application fields.

LEGAL NOTES

The information, and, in particular, the recommendations relating to the application and end-use of Sika products, are given in good faith based on Sika's current knowledge and experience of the products when properly stored, handled and applied under normal conditions in accordance with Sika's recommendations. In practice, the differences in materials, substrates and actual site conditions are such that no warranty in respect of merchantability or of fitness for a particular purpose, nor any liability arising out of any legal relationship whatsoever, can be inferred either from this information, or from any written recommendations, or from any other advice offered. The user of the product must test the product's suitability for the intended application and purpose. Sika reserves the right to change the properties of its products. The proprietary rights of third parties must be observed. All orders are accepted subject to our current terms of sale and delivery. Users must always refer to the most recent issue of the local Product Data Sheet for the product concerned, copies of which will be supplied on request.

SIKA LIMITED

Watchmead
Welwyn Garden City
Hertfordshire, AL7 1BQ
Tel: 01707 394444
Web: www.sika.co.uk
Twitter: @SikaLimited



Product Data Sheet

Sika Boom® Foam Cleaner
May 2026, Version 01.01
020516020000247749

SikaBoomFoamCleaner-en-GB-(05-2026)-1-1.pdf