



METHOD STATEMENT

SikaWrap® Manual Wet Application

03.01.2023 / VERSION 2.3 / SIKA® LIMITED / ROB DOHERTY

CONTENTS

1	Scope	3
2	System Description	3
2.1	References	3
2.2	Limitations	4
3	Products	5
3.1	System Components	5
3.2	Materials Storage	5
4	Equipment	6
4.1	Tools	6
4.2	Cleaning	6
5	Health and Safety	7
5.1	Risk Assessment	7
5.2	Personal Protection	7
5.3	First Aid	7
5.4	Waste Disposal	7
6	Preparation	8
6.1	Pre-Project	8
6.2	Substrate	8
6.3	Resin	9
7	Application	11
7.1	General	11
7.2	Wet Application Process	11
7.3	Additional Overcoating	12
8	Inspection and Testing	13
8.1	Before Application	13
8.2	Site Inspection	13
9	Appendix	14
9.1	Construction Journal	14
9.2	On-Site Checklist: Equipment	14
9.3	On-Site Checklist: Quality Assurance	15
10	Legal Note	16

1 SCOPE

This Method Statement is written as a guideline for the use of the SikaWrap® Composite System. This document shall be used and referred to, in combination with all other relevant Product Data Sheets (PDS), Material Safety Data Sheets (MSDS) and the specific Project Specifications.

Structural strengthening must only be carried out by trained and experienced specialists, if additional clarification or advice is needed, please do not hesitate to contact your local Sika® Technical Services Department who will be pleased to assist you.


This document only describes the manual wet application process. For dry application or wet application using a saturator, please refer to their respective Method Statements.

2 SYSTEM DESCRIPTION

The SikaWrap® Composite System is a high-performance Strengthening System containing FRP fabrics and impregnation resins. They are applied on the strengthening site and formed into a fibre composite. The picture below shows glass*- (left) and carbon- (right) fibre fabrics, with the two-part epoxy-based impregnation resin in the middle.

The main range of applications is as follows:

- Increasing the load bearing capacity of structural elements
- Shear strengthening
- Flexural strengthening
- Masonry strengthening
- Column strengthening (for confinement and / or ductility)
- Changes of building use
- Structural upgrading to comply with current standards
- Improved functionality
- General seismic upgrading and / or retrofitting
- Prevention of damage by seismic action
- Improved seismic performance for masonry walls
- Blast mitigation (accidents or terrorism)
- Impact protection
- Structural design construction defects
- To replace and substitute missing rebars



*Glass fibre fabrics not currently available in the UK

2.1 REFERENCES

This method statement has been written in accordance with the recommendations contained in **fib Technical Report Bulletin No. 14**, especially Chapter 8: "Practical execution and quality control" as well as with the advice contained in **ACI 440.2R-17** and Chapter 10 of **TR55 – Design Guidance for Strengthening Concrete Structures Using Fibre Reinforced Composite Materials**.

Pull-off tests shall be performed according to **BS EN 1542** and considering the values mentioned in the text below.

2.2 LIMITATIONS

- The products must only be used in accordance with their intended applications. The System configuration as described in the Product Data Sheets must be fully complied with and may not be changed.
- The SikaWrap® Systems may only be used by experienced professionals. All strengthening works must be carried out as directed by a suitably qualified Structural Engineer as the Supervising Officer.
- For any other specific construction / build information please refer to the relevant Engineer's specifications, details, drawings, and risk assessments.
- Local differences in product may result in performance variations. The most recent and relevant local Product Data Sheets (PDS) and Material Safety Data Sheets (MSDS) apply.
- Always record the batch numbers for the SikaWrap® Fabrics and Sikadur® resins that are used each day. Additionally at the end of each working day, also check to make sure that the fabric application is uniform and smooth.
- Large mixing quantities of the Sikadur® resins and / or high temperatures result in shortening of the pot-life. In order to prolong the pot-life, reduce the quantity of the mixing components and / or the material's temperature (i.e., store the sealed units in cool conditions until immediately prior to mixing and application).
- For application in cold or hot conditions, pre-condition the resin materials for at least 24 hours in temperature-controlled storage facilities to improve the on-site mixing, application and pot-life limitations.
- Special attention should be paid to the ambient environment and conditions. Observe the minimum / maximum temperatures for substrate, atmosphere and the materials, as well as taking care to avoid application in dew point conditions (application temperature must be 15°C, and at least +3°C above the dew point).
- The substrate moisture content must be less than 4% pbw (percentage by weight). All of the concrete surfaces to be treated must be dry free of surface water or ice.

3 PRODUCTS

3.1 SYSTEM COMPONENTS

Fabric:

Dependent on the application, fabrics with different weights (from 230 g/m² to 930 g/m²) and fabrics with different widths (300 mm, 600 mm) are used. The Table below gives an overview of these different fabric types, weights and widths available:

Sika® Brand	Description	Area Weight [g/m ²]	Available Widths [mm]
SikaWrap®-231 C	Unidirectional woven carbon fibre fabric for installation by the dry or wet application process.	230	600
SikaWrap®-301 C	Unidirectional woven carbon fibre fabric for installation by the dry or wet application process.	300	600
SikaWrap®-600 C	Unidirectional stitched, heavy carbon fibre fabric for installation by the wet application process.	600	300
SikaWrap®-900 C	Unidirectional, fleece stabilized stitched heavy carbon fibre fabric for installation by the wet application process.	900	300
SikaWrap®-930 G	Unidirectional woven glass fibre fabric for installation by the wet application process.	930	600

The fabric rolls are wrapped in PE sheets and packed in cardboard boxes. The standard roll length is 30 or 50 m depending on the product.


Impregnation Resin:

Sika® Brand	Description
Sikadur®-300	Sikadur®-300 is a two-part, epoxy based, low-viscosity, unfilled primer or impregnation resin with an extra-long pot-life and a slow curing speed. It is designed to be used for SikaWrap® Fabric installation by the wet application method.

Additional Products:

Sikadur®-330	Epoxy-based primer, impregnation resin and adhesive
Sikadur®-30	Epoxy-based structural adhesive paste
Sikadur®-41 CF / Rapid	Epoxy-based repair mortar
Sikadur®-52 Injection Normal	Epoxy-based injection resin

3.2 MATERIALS STORAGE



Materials must be stored properly in undamaged, original sealed packaging, in dry cooled conditions at temperatures between +5°C and +25°C (resins), or between +5°C and +35°C (fabrics). Protect all of the products from direct sunlight. Please refer to the specific information contained in the respective Product Data Sheets regarding the minimum and maximum storage temperatures and times. All of these Sikadur® epoxy resin-based products can be stored for up to 24 months from the date of production.

4 EQUIPMENT

4.1 TOOLS



Concrete
Grinder



Vacuum Cleaner



Brush



Application
Trowels



Paint Brush



Hand-Held Mixer



Sika® Plastic
Impregnation
Roller



Paint Roller



Mixing Container



Mixing
Spindle



Mixing Paddle



Scraper

4.2 CLEANING

Clean all tools and application equipment with Sika® Thinner C (or an Isopropanol based cleaner) immediately after use. Any uncured epoxy should be wiped up with a rag wetted with solvent. Hardened material can only be removed mechanically.

5 HEALTH AND SAFETY

5.1 RISK ASSESSMENT



The risks to health and safety from everything including any defects in the structure, working procedures and all of the chemicals used during the materials' installation must be properly assessed and safely accommodated.

Any working areas on platforms and temporary structures must also provide a stable and safe area to work. All work and working procedures must be carried out fully in accordance with the relevant local health and safety legislation.

5.2 PERSONAL PROTECTION

Work Safely!

Safety boots, gloves and other appropriate skin protection should be worn at all times. The use of disposable or new / clean protective clothing during the materials' preparation and application is strongly recommended.

Always wear nitrile based protective gloves when handling epoxy adhesives / impregnating resins, as they can otherwise cause skin irritation. Additionally, apply barrier cream to hands and any unprotected areas of skin before starting work.

Appropriate eye protection should be worn at all times whilst handling, mixing and installing the products. Carrying an eye wash with you at all times is recommended.

Always wash hands with suitable soap and clean water after handling the products and before food consumption, smoking, visiting the toilet and after finishing work.

The work area needs to be well ventilated, and operatives should take frequent breaks in fresh air to avoid any other health issues.

Silica dust produced by the grinding or blast cleaning of concrete can be hazardous. Protect yourself and others by using a vacuum grinder or vacuum blast cleaning equipment with dust extraction and abrasive recycling attachments respectively. Always wear a dust mask / respirator when grinding concrete. Do not inhale the concrete dust.



5.3 FIRST AID

If the epoxy resin based adhesive products come into contact with eyes or mucous membranes, remove any glasses or contact lenses and rinse with clean warm water for 10 to 15 minutes then seek medical attention. Any chemical spillages on skin must be cleaned immediately and rinsed thoroughly with clean warm water.



5.4 WASTE DISPOSAL



Do not empty any surplus material into drainage or water systems; dispose of all waste materials and packaging responsibly through licensed waste disposal facilities or contractors, fully in accordance with local legislation and the relevant authorities' requirements. Also avoid any chemical materials run-off into soil or into waterways, drains or sewers.

Any uncured adhesive waste, spillages and / or leftover Sika® Thinner C must be disposed of as hazardous waste and according to local regulations. Cured adhesive waste can be disposed of safely as normal building materials waste according to local regulations.

For more detailed health and safety information, please refer to the relevant Material Safety Data Sheet (MSDS).

6 PREPARATION

6.1 PRE-PROJECT

Review the project specifications in detail. Inspect the site conditions and the concrete surfaces to receive the treatment and report immediately in writing to the responsible Engineer if anything is unsuitable for proper execution of the works.

Obtain all of the necessary tools and equipment, plus materials required (for a checklist example, see Section 9.2), together with any special project requirements. It is recommended that the SikaWrap® Fabrics to be applied are cut into their prescribed lengths with sharp scissors in advance of the mixing of the Sikadur® resin. Caution should be taken when handling the fabrics to ensure that the fibres are not bent or broken. **Do not fold the fabrics.**

Protect any adjacent surfaces, vehicles etc., surrounding the work area from any dust or damage due to the preparation and execution of the strengthening works.

6.2 SUBSTRATE

The SikaWrap® Strengthening System can be used on concrete, masonry and wooden structures. **Where none of these are specifically mentioned below, then the statements refer to concrete.**

Before preparing the substrate for the application, it must be thoroughly inspected and any unsound material (such as any areas of damaged concrete, pieces of formwork or tie-wires etc.) must be removed.

Where concrete repairs are necessary on a structure prior the application of a SikaWrap® Strengthening System, it is important that the repair materials are designed and installed to be fully compatible with the Sikadur® adhesive and suitable for use in a structural situation (i.e., they must have low shrinkage, compatible modulus of elasticity, good interface bond, adequate strength and an appropriate finished surface).

Repairs to concrete surface irregularities such as blowholes or voids must be made with a suitable repair mortar such as Sikadur®-41, or Sikadur®-31+. Sikadur®-30 adhesive must also be used as a bonding bridge layer for both of these surface repair options, to ensure a good bond with the substrate and no voids in the repairs. Any non-moving structural cracks can be filled by injection with Sikadur®-52 Injection Normal or other suitable Sikadur® injection resin with the Structural Engineer's agreement.

Further advice on all aspects of concrete repairs can be obtained from your local Sika® Technical Services Department.

The actual strength of the concrete substrate must be verified on all projects. If the concrete must be repaired, then another test must be performed after the repairs are completed and adequately cured. Please refer to Section 8 of this Method Statement for more details of testing procedures and the necessary concrete strengths.

Concrete must normally be older than 28 days (dependent on the environmental situation, the mix design and effective strength requirements).

The concrete, stone and masonry substrates must be prepared mechanically using abrasive blast cleaning or grinding equipment. During this preparation work, an integrated vacuum system (see picture on the right) should be used, in order to reduce the risk of contamination, plus a dust mask should be worn to prevent the inhalation of concrete dust.

The mechanical preparation is carried out to remove cement laitance, any loose and friable materials and achieve a profiled, open textured surface. Any surface defects such as honeycombing, blowholes and voids must be fully exposed.



Timber substrates must be planed or sanded to remove all dust and any loose or friable materials completely from all surfaces.

All prepared surfaces must be brushed, air blasted and vacuumed to achieve a dust free condition (see pictures left). No loose particles should be left on any of the substrate surfaces.

External corners and arrises must be rounded to a minimum radius of 20 mm, or as required by the Engineer’s specification. This can be achieved either by grinding, or by building up with Sikadur® epoxy mortars. Internal corners must be made smooth by trowel application of Sikadur® epoxy mortar into the prepared corners.



The surfaces to be strengthened must be levelled to ensure that the specified tolerances are achieved and maintained as detailed in the Table below. The plane and level of the substrate is to be checked with a suitable straight edge. The tolerance required depends on the specified standards to be achieved. The recommended Sika® values are given in the right-hand column of the Table below; however, these tolerances, their method of measurement and testing can be varied on different projects and structures according to any local guidelines and requirements. Obviously, any testing must only be carried out in relation to one standard or another.

Standard	fib Bulletin No. 14	Sika® Recommendation
Tolerance for 2 m length	10 mm	-
Tolerance for 0.3 m length	4 mm	2 mm
Maximum formwork marks	-	0.5 mm



The final surface must be smooth, dry and free of damaged concrete and any other contaminants as dust, foreign particles, cement laitance, oil, grease, surface coatings, curing compounds, waxes and impregnations etc., which could adversely affect or inhibit the bond of the Strengthening System to the concrete.

The substrate moisture content must be less than 4% pbw (percentage by weight).

6.3 RESIN

For the wet application of the SikaWrap® System, Sikadur®-300 is normally used for the resin priming coat and as the impregnating resin, whilst Sikadur®-330 can be used as the resin primer on rougher concrete surfaces (see below). Sikadur®-330 should also be used as primer in the case of heavy fabrics, application overhead or if multiple layers need to be applied, as it increases the green tack of the System. The resins should be mixed and used as described below. Avoid aeration during all mixing actions.

The pot-life begins when the resin and hardener are mixed. It is shorter at high temperatures and longer at low temperatures. The greater the quantity that is mixed, the shorter the pot-life becomes. To obtain longer workability at high temperatures, the mixed adhesive may be divided into portions. Another method is to chill components A and B before mixing them.

The sequence of operations shall be planned to ensure that the adhesive can be applied, joined and the work with it completed within three hours of mixing the adhesive or within 80% of the pot-life, whichever comes first.

For details on the performance, pot-life and other characteristics of the Sikadur® resins products, please refer to the relevant Product Data Sheet.

Resin Primer Coat:

Ground substrates are generally 'smoother', abrasive blast cleaned ones are generally 'rougher'. This difference is the deciding factor for the selection of the most appropriate Sikadur® primer resin. For 'smoother' surfaces, the more liquid resin products such as Sikadur®-300 should be used. When dealing with rough surfaces, the more filled resins such as Sikadur®-330 are best suited to accommodate the surface profile and irregularities.

Sikadur®-330:

Sikadur®-330 serves as primer resin for the fabrics in wet application process. It is supplied in pre-batched units and larger bulk packaging.

Pre-Batched Units:

Continuously mix all of Part A in its container at a low speed (maximum 500 rpm) then gradually add all of Part B until a fully homogeneous mix, with a uniform grey colour and appearance has been achieved. Then pour the whole mix into a clean container and mix for a second time (3 minutes, maximum 500 rpm).

Sikadur®-300:

Sikadur®-300 is used as impregnation resin and it has an extended, longer pot-life and a slow curing speed. It is supplied in pre-batched units.

Pre-Batched Units:

Continuously mix all of Part A in container then gradually add all of Part B continuing to mix at a low speed (maximum 500 rpm) for 3 minutes.

For Partial Quantities:

Accurately weigh (to 1g accuracy) the correct proportions of Parts A and B and pour into a clean container before mixing by the same process as outlined above for the pre-batched units.

Consumption:

The actual consumption, especially of the priming layer, is primarily dependent on the roughness of the substrate and the type and amount of SikaWrap® Fabric to be impregnated. The Table below shows the estimated consumption for the different fabric weights (excluding loss and wastage).

SikaWrap® Product	Area Weight [kg/m ²]	Resin Type	Resin Consumption [kg/m ²]	
			First Layer Including Priming	Following Layers
SikaWrap®-231C	230	Sikadur® 300	1.0-1.2	0.6
SikaWrap®-301C	300	Sikadur® 300	1.1-1.5	0.7
SikaWrap®-600C	600	Sikadur® 300	1.6-1.8	1.0
SikaWrap®-900C	900	Sikadur® 300	2.0-2.2	1.4
SikaWrap®-930G	930	Sikadur® 300	1.6-1.8	1.0

7 APPLICATION

7.1 GENERAL

Prior to starting the application, measure and record the substrate moisture content (to be less than 4%), the relative humidity and determine the dew point. The temperature must be minimum 3°C above the dew point. Cut the SikaWrap® Fabric to the desired dimensions for the installation.

Always work in the same direction as the fibres. Avoid excessive force and moving the roller back and forth when laminating to prevent any folding or creasing of the SikaWrap® Fabric.

Overlapping pieces of fabric must be installed in the same direction as the fibres and the overlap must be at least 100 mm, or according to the project specifications.

When placing several unidirectional SikaWrap® Fabrics side by side, no overlapping in the weft direction (perpendicular to the fibres) is generally required, unless specified otherwise in the strengthening design. For multi-directional fabrics, overlapping in the weft direction must be by at least 100 mm (dependent on the SikaWrap® Fabric type) or again according to the project specifications.

After application, protect the finished installation of SikaWrap® Reinforcement from rain, sand, dust and any other contaminants using protective plastic sheets or other barriers. Do not allow the protective sheets to come into contact with the finished SikaWrap® installation.

7.2 WET APPLICATION PROCESS

The name of the 'wet' application method comes from the state of the fabric at the time it is applied in its final position. For this process, Sikadur®-300 is used as impregnating resin and Sikadur®-330 (rougher substrates, or multiple layers applications or overhead applications) or Sikadur®-300 (smooth substrates) can be used as primer.

The wet application method is suitable for the non-woven fabrics as well as for any woven fabric, especially with an area weight of higher than 300 g/m², depending on the fibre type.

Please refer to the Product Data Sheet for information regarding open time and waiting times between the different primer / resin application steps.

Primer Application

Primer application is the same procedure for manual impregnation or mechanical saturator impregnation. Apply the primer (Sikadur®-330 for 'rougher' substrates, Sikadur®-300 for 'smoother' substrates) to the prepared substrate with a trowel, brush or roller. The Sikadur®-300 resin is very liquid and if necessary, it is possible to apply a second coat after the first coat has penetrated into the concrete substrate.



Manual Resin Application

Distribute 2/3 of the expected Sikadur®-300 quantity on a clean PE sheet and then place the pre-cut fabric onto the resin covered sheet. Saturate SikaWrap® Fabric by rolling with a mohair or plastic roller in the fibre direction until the resin penetrates through the fabric. Distribute the remaining 1/3 of the Sikadur®-300 onto the fabric and evenly spread with roller to fully saturate fabric. Remove the excess resin. The resin consumption can be checked by taking the weight of the fabric before and re-weighing after wetting with Sikadur®-300.

Fabric Positioning / Lamination

Place the pre-wetted, saturated SikaWrap® Fabric onto the primed wet surface in the required direction (within the open time of the primer) and smooth by hand to remove folds, creases and large air entrapments.

The easiest way to transport the impregnated fabric is to roll it onto a cardboard tube as illustrated on the right. This way the fabric is less likely to get distorted or wrinkled. If possible, leave the fabric on the roll for 5-10 minutes, so the resin can soak into the fibre bundles. For a better grip of the fabric to the tube, it is possible to broadcast it with quartz sand before use.



Heavy Fabrics (>600 g/m²)

After smoothing and placement, the fabric is laminated onto the substrate using the Sika® Plastic Impregnation Roller or a squeegee, working parallel to the fibre direction and until the resin is distributed evenly over the fabric and all entrapped air is released. Avoid excessive force when laminating to prevent folding or creasing of the SikaWrap® Fabric.

Additional Fabric Layers

If additional layers are required, repeat the impregnation and lamination process described above. The application must take place wet on wet and within 60 minutes (at +23°C) of the previous layer. If it is not possible to apply the subsequent layers of fabric within 60 minutes of the previous one, then a waiting time of at least 12 hours must be observed before application of the next layer, and again a priming layer is necessary. Take note of the open times mentioned in the Product Data Sheet of Sikadur®-300. In all situations where application is onto a cured layer of the epoxy resin, the surface must be dry and free of dust prior to the application.

The overlapping sections of the additional layers should be distributed around the circumference of the column / beam.

Preparation for Cementitious Overlays

The surface must be wiped until it is clean and dry before application of any coatings to ensure an adequate bond.

If a cementitious overlay is to be applied over the SikaWrap® Fabric, then an additional layer of Sikadur®-300 resin must be applied over final laminating layer (approximately 0.3 kg/m²) and broadcast whilst still wet with a suitable quartz sand, which will improve the adhesion of the overlay (see picture right). If a colored coating is to be applied, the 'wet' Sikadur®-300 surface can also be smoothed with a brush.



7.3 ADDITIONAL OVERCOATING

The applied and cured SikaWrap® Fabric can be coated with a colored protective coating for aesthetic and / or protective purposes. Selection of the appropriate product will be dependent on the exposure requirements. The Table below illustrates some common demands and suitable coating products. Please refer to the relevant Product Data Sheet for specific information on application, properties and performance.

Situation	Special Need	Sika® Solutions
Direct sunlight	UV protection	Sikagard®-550 W Elastic Sikagard®-675 W GB ElastoColor
Application in water	Immersion of product in water, constantly wet substrate	Sikagard®-63 N
Increased fire resistance required	Fire protection	Sikacrete®-213 F

If the top layer of resin was broadcast with a suitable kiln-dried quartz sand, a mortar coat can be applied over the Strengthening System after curing (for example Sikacrete®-213 F for increased fire resistance).

8 INSPECTION AND TESTING

8.1 BEFORE APPLICATION

The substrate strength (concrete, masonry, natural stone) must always be checked and verified in all situations. This is done by means of a series of pull-off tests as outlined in **BS EN 1542**. **The mean adhesive tensile strength of the prepared concrete substrate must be minimum 1 N/mm² (Sika® minimum recommendation) unless otherwise detailed in the Engineer's specifications.**

If the strengthening work has to be performed according to the fib Bulletin No. 14, then the concrete must have a minimum tensile strength of 3 N/mm². Concrete substrates must generally be at least 28 days old.

If the substrate is damaged and needs to be repaired, a repetition of the substrate strength tests is necessary after repair.

8.2 SITE INSPECTION

On site, all aspects of preparation, mixing, and application of materials should be continuously observed and recorded, including the following:

- Surface preparation and testing
- Materials' labels and batch numbers
- Mixing of the resin materials
- Application of the resin to the substrate and the fabric
- Curing of the materials
- System testing
- All other details relating to the strengthening requirement and System specification

Upon completion of the curing process the installed System should be checked again for any areas where the impregnation resin has not fully penetrated, or where any resin has not completely cured. Any such areas covering more than 25 x 25 mm on the surface must be repaired. Any repairs must be made subject to the same application, curing and quality control specifications as the original work.

Small delaminations and / or bubbles can be injected with a compatible Resin System to re-establish bond between the substrate and the Strengthening System.

If large defects are found, removal of the applied System and re-application, or the application of additional layers of CFRP Reinforcement may be necessary. The repair type, the preparatory works, the number of layers to be added and the overlapping lengths must all be approved by the responsible Structural Engineer.

9 APPENDIX

9.1 CONSTRUCTION JOURNAL

Throughout the process of the project work, a record should be written and maintained that details all aspects of the works involved in the preparation, mixing and application, including:

- Surface preparation
- Materials' delivery / batch numbers
- Mixing and application of resin
- Ambient conditions (ambient temperature, substrate temperature, humidity, dew point)
- Any possible contamination
- Details of all test samples and results
- Any significant vibration
- Any other points of note or concern on site

9.2 ON-SITE CHECKLIST: EQUIPMENT

- Brush
- Vacuum cleaner
- Brush roller
- Sika® Plastic Impregnation Roller
- Mixing container
- Hand-Held Mixer
- Mixing spindle
- Mixing paddle
- PE sheets
- Grinding / blast cleaning equipment (dependent on substrate)
- Suitable scissors
- Concrete core drill
- Steel dollies
- Pull-off tester
- Adhesive for dollies
- Thermometer
- Moisture meter
- SikaWrap® Fabric
- Sikadur®-330 resin
- Sikadur®-300 resin
- Sika® Thinner C (or an Isopropanol based cleaner)
- Safety boots
- Safety goggles
- Safety hard hat
- Skin protection cream
- Protective gloves
- Nitrile gloves
- Clean water
- Eye wash kit

9.3 ON-SITE CHECKLIST: QUALITY ASSURANCE

Substrate preparation:	YES	NO
Have 3 pull-off tests been carried out?		
Average value measured on 3 locations: [N/mm ²] (minimum should be 1.0 N/mm ²)		
Are there cracks above 0.2 mm wide in the concrete?		
Have the cracks been injected?		
Has any damage to the substrate been repaired?		
Is the concrete surface even? (see Table in Section 6.2)		
Climate:		
Does the air and surface temperature exceed 10°C?		
The actual average temperature is: [°C]		
Is the ambient temperature at least 3° above the dew point?		
Is the average moisture content of the concrete below 4% (percentage by weight)?		
Is there free-standing water on the surfaces?		
Are the surfaces to be bonded cleaned?		
Is there any dust or other contaminants present?		
After installation:		
Are there any voids in the cured wrap?		
Is there any adhesive with areas of discoloration?		
Have there been any deviations or changes from the initial specification and schedule?		
If Yes, please describe them below:		

10 LEGAL NOTE

The information contained herein, and any other advice are given in good faith based on Sika®'s current knowledge and experience of the products when properly stored, handled and applied under normal conditions in accordance with Sika®'s recommendations. The information only applies to the application(s) and product(s) expressly referred to herein and is based on laboratory tests which do not replace practical tests. In case of changes in the parameters of the application, such as changes in substrates etc., or in case of a different application, consult Sika®'s Technical Services prior to using Sika® products. The information contained herein does not relieve the user of the products from testing them for the intended application and purpose. All orders are accepted subject to our current terms of sale and delivery. Users must always refer to the most recent issue of the local Product Data Sheet for the product concerned, copies of which will be supplied on request.

SIKA® LIMITED

Target Market SCS
Watchmead
Welwyn Garden City
Hertfordshire
United Kingdom
AL7 1BQ

Version Provided By:

Rob Doherty
Phone : 01707 394444
Email : scs.technical@uk.sika.com